

Instruction for usage

- Grasp the handle when full crimping reached, it will open automatically.
- Insert the connector into the saw-tooth section of the crimper as showed in the figure.
- Cut the wire while coating is peeled into the wanted length and insert it into the connector.
- Press the handle until the devices for limiting the pressure is fallen off.
- Open the handle and draw out the connector.

Notice while operating

- Please employ tools connector of adequately for being pressed.
- Don't misuse the connector pressed and the appropriate specification of wire so as to connect rightly and adequately.

To utilize the devices for limiting the pressure until the connector can be pressed tightly and perfectly, otherwise if the handle which fail to open is put to open barely enough, it might cause a great trouble (damaging the tool, connector, or wire). The movable part such as connecting board and axis etc, should be oiled 1-2 times per month or after using.

Don't substitute the hammer or punch for the handle so as not to operate it as the additional functioned-tool.

